



INSTALLATION - CORK Bulletin Boards: Composition Cork

Composition cork can be directly applied to the wall. The wall surface must be clean and free of dust. Painted walls must be sanded and existing wallpaper adhesive must be removed.

Temperature and humidity at the installation site must be maintained at 68 degree F and humidity must be controlled and kept below 68% for 48 hours prior to the installation.

Unroll the composition cork. Reverse the roll; lay flat on the floor to release the natural memory of the material.

Cork panels should be hung vertically. Cut one length of the sheet prepare length of wall by spreading the adhesive according to mfg. recommendation.(Recommended adhesive: Latex-based all purpose adhesive, linoleum paste.)

Work from the top downwards, rolling firmly through the width and the length to insure proper transfer of the adhesive. Remove excess adhesive using a damp cloth and warm water.

It is recommended to fasten the cork on the top edge of the wall using a narrow strip of wood and headless nails. This will prevent the material from sliding down the wall until adhesive is set up (approx.25 minutes). After adhesive is set up remove nails and wood.